

Ergo-Series E6 Barrel Sauna 59D" x 81H"



Note: Please read manual before construction

Front & Back Walls





Tools needed



Wooden front wall installation







DET U Fix it diagonally to make wall more rigid during the installation.

III

Wooden back wall installation







E6 Barrel Sauna 59D" x 81H"







E6 Barrel Sauna 59D" x 81H"





Join two boards together (as shown in diagram II) that will bridge the width of the "A" gap. It is recommended that the combined boards are approximately 1/4" wider than the gap.





If needed, trim the flat edge of the board to create the desired width.



II













12.

E6 Barrel Sauna 59D" x 81H"

