Commercial time set up

CHANGING THE TIME FROM 1 HOUR UP TO 24 HOURS IS A TWO-STEP PROCESS WITH THE MANUAL TOUCHSCREEN (NON-WI-FI) AND MANUAL WI-FI TOUCHSCREEN.

Manual Touchscreen (Non-Wi-Fi):

1st step

1) Hold the - menu + power button for 10 seconds
2) The SEf1 will prompt, turn to on
3) menu out

2nd step

1) - menu +
2) Select SEf1 (it shows 1 hour) use the + to go from 1 hour up to 24 hours
3) menu out

Wi-Fi Touchscreen

1st step

1) Hold the - menu + power button for 10 seconds
2) The S-01 will prompt, turn to on
3) menu out

2nd step

1) - menu +
2) Select S-01 (it shows 1 hour) use the + to go from 1 hour up to 24 hours
3) menu out